

Micropulse Transducers

Rod

Rod housings are mainly used in hydraulic drive applications. When installed in the pressure section of the hydraulic cylinder, the displacement sensor requires the same pressure rating as the actual hydraulic cylinder. In practice, the sensor must be able to withstand pressures up to 1000 bar. The electronics are integrated in an aluminum or stainless steel housing and the waveguide in a pressure-resistant tube made from nonmagnetic stainless steel that is sealed off at the front end with a welded plug. An O-ring in the flange at the opposite end seals off the high-pressure section. An encoder ring with magnets slides over the tube or rod with internal waveguide to mark the position prior to detection.





BTL7 MICROPULSE + General Data 152 Analog Interface 154 Programming 158 SSI Interface 162 Programming 164 Digital Pulse Interface 166 BTL5/BTL6 General Data 168 CANopen Interface 170 Profibus DP Interface 174 Ethernet Interface 176 4 Programmable Switching Points 178 Installation Notices 180

MICROPULSE®



■ www.balluff.com BALLUFF 151





Pressure-resistant to 600 bar, high reproducibility, contact-less, robust

The Micropulse Transducer BTL

is a robust position measuring system for measuring ranges between 25 and 7620 mm under extreme ambient conditions. The actual measurement section is protected inside a high-pressure resistant stainless steel tube. The system is ideal for use in hydraulic cylinders for position feedback or as a level monitor with aggressive media in the food and chemical industries.

Series	Rod BTL7
Shock load	150 g/6 ms as per EN 60068-2-27
Vibration	20 g, 102000 Hz per EN 60068-2-6
Polarity reversal protected	yes
Overvoltage protection	TransZorb protection diodes
Dielectric strength	500 V AC (GND to housing)
Degree of protection as per IEC 60529	IP 68 with cable outlet, IP 67 with screwed-on plug connector BKS-S
Housing material	Anodized aluminum/1.4571 stainless steel protective tube, 1.3952 stainless steel cast flange
Fastener	Style B thread M18×1.5, style Z 3/4"-16 UNF
Pressure rating	
with 10.2 mm protective tube	600 bar with installation in hydraulic cylinder
with 8 mm protective tube	250 bar installed in hydraulic cylinder
Connection	Plug connector or cable connection
EMC testing	
Radio interference emission	EN 55016-2-3 (industrial and residential area)
Static electricity (ESD)	EN 61000-4-2 Severity level 3
Electromagnetic fields (RFI)	EN 61000-4-3 Severity level 3
Electrical fast transient bursts	IEC 61000-4-4 Severity level 3
(BURST)	
Surge voltage	EN 61000-4-5 Severity level 2
Conducted interference induced	EN 61000-4-6 Severity level 3

EN 61000-4-8 Severity level 4

0025...7620 mm in 1-mm increments

Please order separately: USB communication box, page 164

by high-frequency fields

Standard nominal strokes [mm] with an 8 mm protective tube, the max. rated length is 1016 mm

Magnetic fields

Axial cable Connection KA

Plug connector S115
Connection S115

Connector S32
S32 connection




Caution!

Before design, installation and startup please familiarize yourself with the user's guide to be found at www.balluff.com.




Style B (standard design) BTL7____-B-___

Metric mounting thread M18×1.5




Style Z BTL7___-Z-___

3/4" UNF mounting thread




Style B8 BTL7___-B8-___

Metric mounting thread M18×1.5 8 mm protective tube Max. 1016 mm rated length




Style Z8 BTL7___-Z8-___

3/4" UNF mounting thread 8 mm protective tube Max, 1016 mm rated length



Style A BTL7-___-A-___

Metric mounting thread M18×1.5 Flange without 0.5/Ø 25 mm mounting surface





Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7 General Data Analog Interface Programming SSI Interface Digital Pulse Interface

Rod BTL5/BTL6
General
Data
CANopen
Interface
Profibus DP
Interface

Ethernet Interface 4 Programmable Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories



Compatible with BTL5

Features of Micropulse BTL7-A/C/E/G...B, Z, A

- Status LEDs for indicating operating status and diagnostics
- Extended application range due to high degree of protection IP 68 (cable version)
- Electronics head can be replaced in the event of service
- Compact housing, saves space
- Error signal, no position encoder within measuring range

Flexible measuring range

The start and end point of the measuring range can be adapted to the application. The points are set using the included calibration device directly on the unit or remotely, see page 158.


Transducer interface Customer device interface Part number Output voltage
Part number Output voltage
Output voltage
· · · · · · · · · · · · · · · · · · ·
Output current
Load current
Max. residual ripple
Load resistance
System resolution
Hysteresis
Repeat accuracy
Measurement rate, length-dependent
Max. linearity deviation
Temperature coefficient
Supply voltage
Current consumption at 24 V DC
Polarity reversal protected
Overvoltage protection
Dielectric strength
Operating temperature



Series




Rod BTL7	Rod BTL7	Rod BTL7	Rod BTL7
Analog	Analog	Analog	Analog
Α	G	E	C
Analog	Analog	Analog	Analog
BTL7- A 110-M	BTL7- G 110-M	BTL7- E 1_0-M	BTL7- C 1_0-M
010 V and 100 V	-1010 V and 1010 V		
		420 mA or 204 mA	020 mA or 200 mA
Max. 5 mA	Max. 5 mA		
≤ 5 mV _{pp}	≤ 5 mV _{pp}		
		≤ 500 Ω	≤ 500 Ω
≤ 0.33 mV	≤ 0.33 mV	≤ 0.66 µA	≤ 0.66 µA
≤ 5 µm	≤ 5 µm	≤ 5 µm	≤ 5 µm
System resolution/min. 2 µm			
Max. 4 kHz	Max. 4 kHz	Max. 4 kHz	Max. 4 kHz
±50 µm to ≤ 500 mm rated length	±50 µm to ≤ 500 mm rated length	±50 µm to ≤ 500 mm rated length	±50 µm to ≤ 500 mm rated length
±0.01% 5015500 mm rated length			
$\pm 0.02\%$ FS > 5500 mm rated length	$\pm 0.02\%$ FS > 5500 mm rated length	$\pm 0.02\%$ FS > 5500 mm rated length	$\pm 0.02\%$ FS > 5500 mm rated length
≤ 30 ppm/K	≤ 30 ppm/K	≤ 30 ppm/K	≤ 30 ppm/K
2028 V DC	2028 V DC	2028 V DC	2028 V DC
≤ 150 mA	≤ 150 mA	≤ 150 mA	≤ 150 mA
yes	yes	yes	yes
yes	yes	yes	yes
500 V AC (GND to housing)			
- 40+85 °C	-40+85 °C	-40+85 °C	-40+85 °C



Ordering example:

or 20...0 mA



8

Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7

Genera**l** Data

Analog Interface

Programming SSI Interface Digital Pulse Interface

Rod BTL5/BTL6
General
Data
CANopen
Interface
Profibus DP
Interface
Interface
Interface
A Programmable
Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories




USB configurable

Position and velocity

Two outputs can be assigned any position value and velocity signal using the USB interface.


Mode examples:

Double position encoder




2 encoders, 2 movements, 2 output signals

Differential



Differential signal between 2 position encoders, position and difference possible

Velocity



Velocity output

Output signal Transducer interface Position signal interface, customer device Part number Output signal factory setting Output signal can be adjusted via configurable USB Load current Max. residual ripple Load resistance System resolution Current consumption at 24 V DC Hysteresis Repeat accuracy Measurement rate, length-dependent Max. linearity deviation Temperature coefficient Supply voltage Polarity reversal protected Overvoltage protection Dielectric strength Operating temperature

Micropulse⁺ USB configurable BTL7-A/E501

- Simple configuration and adjustment of the start and end point via the USB interface, quick startup
- "Easy Setup" for manual adjustment on-site
- Configurable dual output functions, position and speed
- Increased operating reliability with status LEDs for indicating the operating status and diagnostic information
- Extended application range due to high degree of protection IP 68 (cable version)
- $\hfill\blacksquare$ The electronics head can be replaced in the event of service
- Compact housing

Series

■ Error signals, no position encoder within measuring range


Please enter code for output signal, rated length, design and connection in the part number.

Scope of delivery


- Transducer
- Calibration device
- Quick start instructions

Please order separately:
USB communication box, see page 159
Position encoders, see page 218
Floats, see page 216
Fastening nut, see page 219
Plug connectors, see page 252

Rod BTL7	Rod BTL7
Analog	Analog
A	E
Analog	Analog
BTL7- A501- M	BTL7- E501- M
010 V and 100 V	420 mA and 204 mA
-1010 V and 1010 V	020 mA and 200 mA
Max. 5 mA	
≤ 5 mV _{pp}	
	≤ 500 Ω
≤ 0,33 mV	≤ 0.66 µA
≤ 150 mA	≤ 180 mA
≤ 5 µm	≤ 5 µm
System resolution/min. 2 µm	System resolution/min. 2 µm
Max. 4 kHz	Max. 4 kHz
±50 µm to ≤ 500 mm rated length	±50 µm to ≤ 500 mm rated length
±0.01% FS > 5005500 mm rated length	±0.01% FS > 500≤ 5500 mm rated length
±0.02% FS > 5500 mm rated length	±0.02% FS > 5500 mm rated length
≤ 30 ppm/K	≤ 30 ppm/K
1030 V DC	1030 V DC
yes	yes
yes	yes
500 V AC (GND to housing)	500 V AC (GND to housing)
−40+85 °C	−40+85 °C



Ordering example:





Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7

General Data

Analog Interface

Programming SSI Interface Digital Pulse Interface

Rod BTL5/BTL6
General
Data
CANopen
Interface
Profibus DP
Interface
Ethernet
Interface
4 Programmable
Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories

Basic



Quick commissioning

Setting options for the start and end point

	BTL7 Standard	BTL7-A/E501 Micropulse ⁺ USB configurable
1. Calibration device		
Teach-in		
Adjusting		
Online setting		
Easy Setup		
2. Remote setup, calibration box		
3. USB configuration		

1. Calibration device

100% start and end point calibration

The start and end points of the analog signal can be set to the optimal position at the touch of a button. Depending on the application, "teach-in" or "adjust" mode is used, selectable by pressing a button combination. Two-color LED indicators assist the procedure.

Easy Setup

For BTL7-A/E501 Micropulse only. Simple programming mode for adjusting the start and end point of the transducer to the current application in just a few steps. The position encoder is brought into the new position. Confirm by pressing a button. The "Adjust" function allows the new value to be fine-tuned for a stationary encoder. No error value is output during the setup procedure.

Adjusting

Here you can adjust to a new start and end value. This may be required when you cannot physically move the encoder to the start and/or end point. Move the encoder to the new start and end position, and adjust the displayed value by pressing the button until the desired output values are reached.

Online setting


This programming function allows you to set the start and end point while in run mode, such as in a closed loop configuration. No error value is output during the setup procedure. The calibration range is limited to $\pm 25\%$.

Teach-in

The beginning and end points set at the factory are to be replaced by the new beginning and end points.

In addition, the position encoder must first be brought into the new beginning position and then into the new end position, and the respective values stored by pressing the button.

Set start and end points using the BTL7-A/EH01 calibration device, included in the scope of delivery.




Selecting the calibration procedure BTL7 Standard

Procedure for teach-in, rising signal


before — — — — after

1. Move the position encoder into the new zero position.




Take over new zero value

2. Move the position encoder into the new end position.



Take over new end value

3. Newly set measurement path






2. Remote setup


Setting the start and end points using programming inputs

If the transducer is located in an inaccessible place or a hazardous area, the start and end point can be adjusted remotely. Teach-in, adjustment and online setting are identical to programming with the calibration device. Button 1, blue, corresponds to programming input $L_{\rm a}$ and button 2, gray, to input $L_{\rm b}$.

Remote setting of the start and end points using calibration box

With the Calibration Box BTL-A-CB02, the characteristic of the position measuring system can be easily and quickly adapted to the requirements of the hydraulic cylinder and the application. With simple plug & play, without PC, laptop or extensive software downloads, the measuring range as well as the slope of the output characteristic are set. The setting option saves storage and setup costs, since one Micropulse BTL7 can fulfill different requirements that, in the past, required several systems.





Set the output characteristic with the calibration box. Zero and end points, measuring range, rising and falling characteristic

Calibration box with cable set		
Part number	Cable set	
BTL7-A-CB02	Cable connection	
BTL7-A-CB02-S115	Plug connector S115	
BTL7-A-CB02-S32	Connector S32	



Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7 General Data Analog Interface

Programming SSI Interface

Digital Pulse Interface Rod BTL5/BTL6 General Data

CANopen Interface Profibus DP Interface Ethernet Interface 4 Programmable Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories

159



3. USB configuration

Start, end value setting and configuration via USB

The Micropulse Configuration Tool software allows the quick and easy configuration of Balluff transducers of type BTL7-A/E501... on a PC.

The most important features are:

- Online display of the current position of the encoder
- Graphical support for setting the functions and characteristics
- Display of information about the connected transducer
- Selectable number formats and units for display
- Reset to factory settings possible
- Calibration device can be disabled
- Demo mode without having a transducer connected

Connecting the USB communication box

For model BTL7-A/E501-M...-S32/S115 transducers, the communication box can be switched between the transducer and the controller. The communication box is connected to the PC using a USB cable.

USB communication box	
Part number	with cable sets
BTL7-A-CB01-USB-S32	Connector S32
BTL7-A-CB01-USB-S115	Plug connector S115
BTL7-A-CB01-USB-KA	Cable connection


Scope of delivery

- USB communication box
- Cable set
- Quick start instructions

The PC software and the corresponding manual are available on the Internet at www.balluff.com/downloads-btl7

System requirements

- Standard PC
- Operating system: Windows 2000/XP/Vista/7
- Screen resolution at least 1024 × 768 pixels
- 10 MB available hard disk space
- Install Java Runtime Environment (JRE) Version 1.4.2 or higher http://java.com/getjava
- USB port



Caution!

Before design, installation and startup please familiarize yourself with the user's guide to be found at www.balluff.com.



Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7 Genera**l** Data Analog Interface

Programming

SSI Interface Digital Pulse Interface

Rod BTL5/BTL6

Genera**l** Data

CANopen Interface Profibus DP Interface

Ethernet Interface

4 Programmable Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories



outstanding linear and synchronous performance

SSI interface Micropulse standard for asynchronous operation BTL7-S5__-M____-B-___

The synchronous serial data transmission is suitable for controllers from different manufacturers.

Reliable signal transmission, even with cable lengths of up to 400 m between the controller and the BTL transducer, is assured by interference-free RS485/422 differential drivers and receivers. Any interference signals are effectively suppressed.

SSI interface Micropulse Plus for asynchronous operation BTL7-S510-M_ _ _ _-B-_ _ _

Functions, interface parameters and measuring range can be set via an integrated USB interface.

SSI interface Micropulse Standard for synchronous operation BTL7-S5_B-M___-B-___

Micropulse Transducers with synchronized SSI interface are well suited for dynamic control applications. Data acquisition in the transducer is synchronized using the external clock of the controller, allowing an optimum speed calculation to be performed in the regulator/controller.

Prerequisite for this synchronous method of transducer operation is time stability of the clock signal.

The **maximum scan rate** f_A , with which a new, current value is available on each sampling, can be approximated from the table to the right. An exact diagram can be found in the current user's guide.


SSI interface Micropulse Plus for synchronous operation BTL7-S510B-M____-B-___

Via an integrated USB interface, functions,

Functions, interface parameters and measuring range can be set via an integrated USB interface.


The clock frequency depends on the cable length.

Behavior of LED 1 and the error value over the entire range



LED indicator





BTL7-S5... with evaluation/controller, connection example



Rated length range			Scan rate				
	25 mm	<	Rated length	≤	150 mm	:	4050 Hz
	150 mm	<	Rated length	≤	300 mm	:	3250 Hz
	300 mm	<	Rated length	≤	500 mm	:	2200 Hz
	500 mm	<	Rated length	≤	1000 mm	:	1200 Hz
	1000 mm	<	Rated length	≤	2000 mm	:	650 Hz
	2000 mm	<	Rated length	≤	7620 mm	:	170 Hz

Cable length	Clock frequency
< 20 m	< 1000 kHz
< 50 m	< 600 kHz
< 100 m	< 330 kHz
< 200 m	< 180 kHz
< 400 m	< 90 kHz

LED 1	
Green	Normal function
	The position encoder is within the limits
Red	Error
	No position encoder, or position encoder is
	outside the limits

LED 2	
Green	Synchronous operation
	Internal measurement is synchronous with SSI query
Off	Asynchronous operation
	Internal measurement is asynchronous with SSI query
Flashing	Programming mode
green	Only with BTL7-S510(B)





Series	Rod BTL7
Output signal	Synchronous-serial
Transducer interface	S
Customer device interface	Synchronous-serial
Part number - Standard asynchronous	BTL7-S5M
Part number - Plus asynchronous	BTL7-S510-M
Part number - Standard synchronous	BTL7-S5_ _B -M
Part number - Plus synchronous	BTL7-S510 B -M
System resolution depending on model (LSB)	1, 2, 5, 10, 20, 40, 50 or 100 µm
Repeat accuracy	≤ 11 µm, typical ±2 µm
Hysteresis	≤7 µm
Max. linearity deviation	±30 µm with 5 and 10 µm resolution or ≤ ±2 LSB
Temperature coefficient, typical	≤ 15 ppm/K
Supply voltage, stabilized	1030 V DC
Current consumption	≤ 120 mA
Operating temperature	− 40+85 °C
Storage temperature	- 40+100 °C

8

Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

TTOTILC DIW

Rod BTL7 General Data Analog Interface Programming

SSI Interface

Digital Pulse Interface

Rod BTL5/BTL6 General Data CANopen Interface Profibus DP Interface

Ethernet Interface 4 Programmable Switching Points

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories


Basic Information and Definitions

Scope of delivery


■ Transducer

Quick start instructions


Please enter code for coding, system resolution, rated length, design and connection in the part number.



Order example BTL7-S standard:



Order example BTL7-S Plus:



Rod BTL7 Programming

Micropulse Plus BTL7-S510_-... with USB interface Configuration via USB

The BTL7-S510_-... transducers can be configured quickly and easily on a PC.

The most important features are:

- Online display of the current position of the encoder
- Graphical support for setting the functions and characteristics
- Display of information via the connected transducer (model, serial number, firmware version, nominal length, SSI output signal)
- Selectable number formats and units for display
- Reset to factory settings possible
- Demo mode without having a transducer connected

System requirements

- Standard PC
- Operating system: Windows 2000/XP/Vista/7
- Screen resolution at least 1024 × 768 pixels
- 10 MB available hard disk space
- Install Java Runtime Environment (JRE) Version 1.4.2 or higher http://java.com/getjava
- USB port


Configuration options of the position measuring system BTL7-S510 $_$ -...

- Number of position encoder 1 or 2
- Position
- Velocity
- Differential position
- Speed difference

Interface configuration

- Start/end point
- Rising/falling signal
- Error value
- Data format
- Code
- Resolution

The PC software and the corresponding manual are available on the Internet at www.balluff.com/downloads-btl7






Connecting the USB communication box

With the BTL7-S510-M... transducers, the communication box can be connected between the transducer and controller. The communication box is connected to the PC using a USB cable.

USB communication box with cable set	
Part number	Cable set
BTL7-A-CB01-USB-S32	Connector S32
BTL7-A-CB01-USB-S115	Plug connector S115
BTL7-A-CB01-USB-KA	Cable connection

Scope of delivery

- USB communication box
- Cable set
- Quick start instructions



Caution!

Before design, installation and startup please familiarize yourself with the user's guide to be found at www.balluff.com.



Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW Rod BTL7

General Data Analog Interface

Programming SSI Interface Digital Pulse Interface

Rod BTL5/BTL6 General Data

CANopen Interface Profibus DP Interface Ethernet Interface

4 Programmable Switching Points Installation

Notices

Rod Compact
and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories

Basic Information and Definitions

165




cost-effective and synchronous performance

Profibus BNI modules are an elegant, cost-effective solution from Balluff.

The modules have a robust metal housing that was designed for use in harsh industrial environments and is capable of withstanding powerful mechanical loads. The modules have four independent ports for Micropulse Transducers BTL with P511. A maximum of 16 encoders can be used per BTL port. The maximum rated length here is 7500 mm. Depending on the version, four additional ports with digital or analog sensors can be assigned. You can achieve maximum functionality and cost efficiency for fieldbus integration by combining Micropulse Transducers BTL with Profibus modules P111.

For more information, see page 268



Highly accurate digitalizations of the P511 pulse signal

encoders per BTL is 16; however altogether, it is 60 per module.

Companies developing their own electronic control and processor units can create a highly accurate P interface cost-effectively and with minimum effort using the Balluff digitizing chip. The digitizing chip was developed as a high-resolution, configurable ASIC for Micropulse transducers with P pulse interface.


Digitizing chip 44QFP

P511 interface – Cost savings using DPI/IP for start-up and installation

DPI/IP is a protocol for direct data exchange between a controller and transducer. The signal lines are used to send additional information such as manufacturer, measuring length and waveguide gradient. This allows start-up or replacement of a transducer without having to make manual changes to the controller parameters.

Features


- Bi-directional communication
- Position measurement system controller using Init and start/stop signals
- Integrated diagnostic functions
- Plug and Play
- Automatic configuration shorter downtimes
- Transmission of sensor type, measuring length, specific parameters
- Measurement length up to 7,620 mm



Block diagram of P interface

Benefits

- High position resolution: the actual 1 µm resolution of the BTL position measurement system is supported by the 133 ps resolution of the chip (at low clock frequency 2 or 20 MHz).
- Position data from 4 position encoders can be processed simultaneously
- 4/8-bit processor interface






Digital Pulse Interface

Series	Rod BTL7
Transducer interface	Pulse P511
Customer device interface	Pulse P511
Part number	BTL7- P 511-M
System resolution	processing-dependent
Repeat accuracy	typ. ±2.5 µm
Hysteresis	≤ ±7 µm
Linearity deviation	±50 µm up to 500 mm rated length
	typ. ±0.01% 5015500 mm rated length
	typ. ±0.02 % 55007620 mm rated length
Ultrasonic speed (standardized)	2850 m/s
Gradient (standardized)	8.9122807 µs/inch
Supply voltage	1030 V
Current consumption at 24 V	120 mA
Operating temperature	-40+85 °C
Storage temperature	-40+100 °C

The rising and falling edges can be evaluated.



INIT

Please enter code for rated length, design and connection in the part number.


Scope of delivery

■ Transducer

Quick start instructions

Please order separately: Position encoders, see page 218 Floats, see page 216 Fastening nut, see page 219 Plug connectors, see page 252

Ordering example:



8

Micropulse Transducers

Profile P

Profile PF

Profile AT

Profile BIW

Rod BTL7 General Data Analog Interface Programming SSI Interface

Digital Pulse Interface

General Data CANopen Interface Profibus DP Interface Ethernet Interface 4 Programmable Switching Points

Rod BTL5/BTL6

Installation Notices

Rod Compact and Rod AR

Rod EX, T Redundant and CD

Filling Level Sensor SF

Accessories

Basic Information and Definitions

■ www.balluff.com BALLUFF | 167